

## **AV1-1 HEPA Air Operated Industrial HEPA Vacuums**





## Industrial Vacuums for Hazardous Materials

### Compressed Air Industrial **HEPA<sup>Plus</sup>** Vacuums

PrestiVac Compressed Air Industrial **HEPA<sup>Plus</sup>** Vacuums are specifically designed to safely vacuum toxic, nuisance, hazardous dusts. Absolute **HEPA<sup>Plus</sup>** filtration with an efficiency of 99.995% @ 0.2 micron captures all of the hazardous dust and ensures the exhaust air is clean, keeping the operator and the environment safe from exposure and contamination.

#### Features:

- Powerful Suction - High Performance
- Air operated Pneumatic unit with no electrical components or moving parts so it can run continuously and

- will not overheat or breakdown
- Static dissipating ESD safe
- All Stainless steel construction makes it a solid unit that is easy to clean and sterilize
- Complete with static dissipating suction hose and accessories
- Quiet operation with only 72 dB

**Filtration System:**

- Washable, reusable main filter for dust and solids
- **HEPA<sup>Plus</sup>** Filtration with an efficiency of 99.995% @ 0.2 micron. Testing Method: IEST RP-CC034.3. H14. MIL-STD 282 / A.S.T.M. - D2986-91. MPPS method EN 1822.

**Applications:**

- Debris
- Dust
- Machine shops
- Maintenance/House keeping
- Metal Chips

**Specifications:**

| Model                 | AV1-1 HEPA |
|-----------------------|------------|
| Air Flow (CFM)        | 120        |
| Vacuum Pressure (H2O) | 200        |
| Collection Type       | Dry        |
| Capacity (gal)        | 1          |
| dB(A) @ 6 ft          | 72 dB      |
| Air Line Size (I.D.)  | 0.5"       |
| Input Pressure (PSI)  | 80 to 100  |
| Input Air Flow (CFM)  | 35         |

**\*\*Optional 3/8" (9.5 mm) I.D. Air Line Configuration Also Available\*\*****Included Accessories:**

- Suction hose assembly 1.25" (38mm) x 10' (3m)
- Air Suction hose assembly 0.5" x 25'
- Floor tool
- Crevice tool
- Round brush

**Optional Accessories:**

- Extension wand
- Single bend wand
- Flat tool
- Wall brush

**Filtration Options:**

- **ULPA** Filtration with an efficiency of 99.9995% @ 0.12 micron. Testing Method: IEST RP-CC034.3. H15. MIL-STD 282 / A.S.T.M. - D2986-91. MPPS method EN 1822.

If you have a special application or specific requirement, please feel free to contact us. As manufacturers, we can modify our units to meet your specific needs.

Hepa Vacuums, AIR OPERATED